

## Giving Assignments

1. Launch guideWELD VR




2. Click PLAY at Configuration Screen



### 3. Login with your Instructor Account Credentials




### 4. Click Edit Class button



### 5. Edit Class Assignments

Add Assignments to the class by clicking the "+" sign next to the welds you want to add on the left side under Available Assignments shown in figure 1. The Assignment is assigned to the class shown in figure 2. Repeat for as many Assignments the class will need. Click the BACK button in the lower left when finished.



### 6. Assignments Now Showing for Class

